


# **SINGER**

## **403A**

# List of Parts—Machine No. 403A

Machine No. 403A




## ATTACHMENT SET 161279

8879	Felt Washer (4)
51361(813)	Bed Plate Screw
51621(813)	Bed Plate Nut
81200	Rinder
161133	Tube of Oil
161166	Zipper Foot
161167	Applique Foot
161168	Button Foot
161195	Hemmer Foot
161276	Lint Brush
161278	Attachment Box
161294	Screwdriver (IG)
161295	Screwdriver (SM)
161561	Ruffler
170071-001	Presser Foot
172007	Spool Pin (3)
172185	Fashion Disc 1
172191	Fashion Disc 5
172229	Fashion Disc 6
172230	Fashion Disc 7
172336	Robbin (plastic) (4)
174527	Fashion Disc 9
171324 174528	Fashion Disc 8
171323 174529	Throat Plate
174533	Fashion Disc 10
174540	Fashion Disc 11
2020(15x1)	Needles 14 (3) 16 (3)



# List of Parts—Machine No. 403A



9882 MIC 3

